


BT™
BT Omega™



description	item no.	description	item no.
1 Tank Adaptor	17044	25 Short Tank Adapter Bolt	19440
2 Complete Valve Assembly	19382	26 Bolt Handle Rubber Cover	19445
3 Power Tube	19384	27 Trigger Return Spring	19446
4 Feed Elbow (complete)	19385	28 Drive Spring	19447
5 Ball Detent	19386	29 Drive Spring Guide	19448
6 Bolt Plug	19389	30 Sear Spring	19449
7 Barrel Adapter	19391	31 Barrel Adaptor O-Ring	19452
8 Trigger Plate Spacer	19404	32 Bolt handle	19454
9 Sear	19405	33 Rear Bolt	19455
10 Front Bolt	19409	34 Stock (complete)	19280
11 Linkage Arm	19410	35 Barrel Assembly (complete)	19281
12 Receiver Nuts	19415	36 Right Receiver	19282
13 Valve Screw	19416	37 Left Receiver	19283
14 Velocity Screw	19418	38 Magazine	19284
15 Feed Elbow Pinch Bolt	19420	39 Omega Name Plate	19285
16 Feed Elbow Nut	19421	40 Grips (left and right side)	19287
17 Feed Elbow Washer	19422	41 Trigger Plate	19288
18 Tank Adapter Nuts	19423	42 Trigger Plate Pin	19289
19 Front Bolt O-Ring	19424	43 Trigger Assembly	19290
20 Rear Bolt & External Valve O-Ring	19426	44 Safety With Orings	19291
21 Shock Absorber O-Ring	19427	45 Blanking Plug	19293
22 Grip Screws	19430	46 Short Receiver Screw	19294
23 Gas Line	19435	47 Long Receiver Screw	19295
24 Long Tank Adapter Bolt	19439	48 Lower Frame Screw	19296