


Spyder Aggressor



Item #	Name of Parts
14	Valve body
15	Valve body screw
16A	M5 X 12.5 Screw
2017H	Venturi bolt
18A	Striker
19A	Striker O-ring
20	Barrel O-ring
21	Bolt pin
22B	Bolt screw
23B	Quick Disconnect Pin
23C	Disconnect Lock Pin
25	Striker spring
26A	Striker buffer
27	Striker spring guide
27A	Flat disc
28C	Striker plug
1928C	Striker plug (blue)
29B	Lock Screw
29D	Thumb Adjuster w/ lock screw (blk)
1929C	Thumb Adjuster w/ lock screw (blue)
1931U	Aggressor Deluxe Trigger Frame
32E	Rubber Grip Cover
33C	Grip Cover Screw
35M	C/A Adapter (black)
1935M	C/A Adapter (blue)
35N	Drop Forward (black)
1935N	Drop Forward (blue)
33F	Nut Screw
36D	5/32" X 5/8" w/ washer (black)
36E	Screw 5/32" X 7/8" (black)
37M	Disconnect hose
37A	Filter O-ring
37B	Filter
37C	#011 O-ring
37D	Plastic Washer
38A	Safety button
39B	Cocking knob

42	Male to Male Adapter
47D	Sight Rail w/ Beaver Tail (black)
1947D	Sight Rail w/ Beaver Tail (blue)
2041	Spare Parts Kit
5814	Double Trigger
48	Trigger Roll Pin
49	Sear Roll Pin
49A	Secondary Sear Roll Pin

Item #	Name of Parts
1906	Aggressor Receiver (purple/blue)
2008	Aggressor Reservoir Plug (blue/blk)
1908	Aggressor Reservoir Plug (purple/blue)
9	O-ring #015 80D
10	Valve spring
11	Cup seal guide
12	Cup seal
13	Valve pin

Item #	Name of Parts
1	Barrel plug
2002	Aggressor Barrel (cobalt/blk)
1902	Aggressor Barrel (purple/blue)
3	Ball Stopper
4B	Delent Cover
2004G	Direct Feed (cobalt/blk)
1904G	Direct Feed (purple/blue)
5B	M4X6 screw
05C	Direct Feed Screw M4X8 w/ washer
7	M5X14 Screw w/ washer
2006	Aggressor Receiver (blue/blk)